Mandis shop

T4

Original	Replacement	Original	Replacement
Power	Power		
AUX	Red		
Digital	Blue		
Bluetooth	Green		
Play	Play		
Pause	Pause		
>>I	>>I		
I<<	I<<		
Vol+	Vol +		
Vol-	Vol -		

https://remotecontrols.dk/en/CREATIVE/1062147-89784-replacement-remote-control-for-CREATIVE-T4.html