Mandis shop

Daewoo SG331

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Program | TV/ Radio / | | |
| - 10 | Guide / EPG / -/-- | | |
| +10 | Fav / Marker / PC | | |
| Play/ Pause | Play / Slow | | |
| Stop | Stop / Hold | | |
| I << | I << / Preset- | | |
| >>I | >>I / Preset + | | |
| Repeat | Green / APP / Repeat | | |

https://remotecontrols.com/Daewoo/1051-797-replacement-remote-control-for-Daewoo-SG331.htm