Mandis shop

Denon RC-270

Original	Replacement	Original	Replacement
Power	Power	Rec	Rec
Prog/Direct	Sleep	>>I	>>I
1	1	I<<	I<<
2	2	>>	>>
3	3	<<	<<
4	4	Time	AV
5	5	Clear	Exit
6	6	Enter	Ok
7	7	Title	Info
8	8	Character	Options
9	9	Edit	TV/R
10	0	Repeat 1/ALL	Text
+10	Guide	Repeat A-B	D. Menu
Call	Pre Ch	Random	Media
Play	Play	Eject	Eject
Pause	Pause	Memory Rec	Format
Stop	Stop	Synchro Rec	3D

https://remotecontrols.dk/en/Denon/1056900-86420-replacement-remote-control-for-Denon-RC-270-00D3990473003.html