Mandis shop

DIG002

Original	Replacement	Original	Replacement
Power	Power		
Open/Close	Eject / Surround		
Skip +10 Folder	0		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
>>I	>>I / Preset+		
I<<	I<< / Preset-		
Vol+	Vol+		
Vol-	Vol-		

https://remotecontrols.dk/en/Digital/1066613-82460-replacement-remote-control-for-Digital-DIG002.html