| Original | | Replacement | |
|---|---|---|---|
| Power | Power | Power | Power |
| TV/R | TV/R | SEARCH TV/R | TV/R |
| Code | APP | APP MEDIA | Media |
| Mute | Mute | MUTE | Mute |
| 1..:@ | 1 | 1 | 1 |
| 2abc | 2 | 2 | 2 |
| 3def | 3 | 3 | 3 |
| 4ghi | 4 | 4 | 4 |
| 5jkl | 5 | 5 | 5 |
| 6mno | 6 | 6 | 6 |
| 7pqrs | 7 | 7 | 7 |
| 8tuv | 8 | 8 | 8 |
| 9wxyz | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| Info | Info | DISPLAY INFO | Info |
| PiP | PiP | HOME SMART | Smart |
| VOL+ | Vol + | + VOL | Vol + |

| Original | | Replacement | |
|---|---|---|---|
| VOL- | Vol - | VOL – | Vol - |
| Back | Back | RETURN BACK | Back |
| Exit | Exit | CLEAR EXIT | Exit |
| CH+ | CH+ | + CH | Ch + |
| CH- | CH- | CH – | Ch - |
| EPG | EPG | -/-- GUIDE | Guide |
| Menu | Menu | TOP MENU MENU | Menu |
| Up | Up | Up | Up |
| Left | Left | Left | Left |
| OK | OK | OK | Ok |
| Right | Right | Right | Right |
| Down | Down | Down | Down |
| REC | Rec | REC MODE | Rec |
| PVR | PVR | SETTINGS OPT | Options |
| Play / Pause | Play / Pause | PLAY MODE ▶ | Play |
| Play / Pause | Play / Pause | ⏸ | Pause |
| Stop | Stop | ■ | Stop |

| Original | | Replacement | |
|---|---|---|---|
| | << | | << |
| | >> | | >> |
| Mark | Mark | ECO 3D | 3D |
| List | List | DISC NAV LIST | List |
| Audio | Audio | SOUND DUAL | Dual |
| Fav | FAV | FAV PRE-CH | Pre Ch |
| Sleep | Sleep | PROG SLEEP | Sleep |
| Pup | Pup | SHIFT + CH + | Shift + Ch + |
| Sub | Sub | AD SUBT | Subt |
| Fav+ | Fav+ | | >>I |
| Text | Text | REPEAT TEXT | Text |
| Pdn | Pdn | SHIFT + CH − | Shift + Ch - |
| Zoom | Zoom | ZOOM | Eject |
| Fav- | Fav- | | I << |
| | Red | A | Red |
| | Green | B | Green |
| | Yellow | C | Yellow |

| Original | | Replacement | |
|---|---|---|---|
| | Blue | D | Blue |