Mandis shop

LG AKB74935621

Original		Replacement	
	Power		Power
F	F	TOP MENU MENU	Menu
OPTICAL	Optical	SETTINGS OPT	Options
STANDARD	Standard	HOME SMART	Smart
BASS BLAST	Bass Blast	APP MEDIA	Media
VOL +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
	I <<		I <<
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
DRC ON	DRC On	+ CH	Ch +
DRC OFF	DRC Off	CH –	Ch -
WOOFER LEVEL +	Woofer Level +		Up
WOOFER LEVEL –	Woofer Level -		Down
AUTO POWER ON	Auto Power On		Right

Original		Replacement	
AUTO POWER OFF	Auto Power Off		Left

https://remotecontrols.com/LG/10625-957-replacement-remote-control-for-LG-AKB74935621.htm