Original		Replacement	
	Power		Power
	TV / Rad	TV/R	TV/R
	Audio	DUAL	Dual
	Text	TEXT	Text
	App	MEDIA	Media
	List	LIST	List
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Menu	MENU	Menu
	EPG	GUIDE	Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok

Original		Replacement	
	Back	BACK	Back
	Exit	EXIT	Exit
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	i	INFO	Info
	Mute	MUTE	Mute
	Prog +	CH +	Ch +
	Prog -	CH -	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original	Replacement	Original	Replacement
0	0		