Mandis shop

Panasonic N2QAYB001060

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Cancel		Pre Ch
	Audio		Dual
	Open/Close		Eject
	Status		Info
	Miracast		TV/R
	Internet		Shift + Media

Original		Replacement	
	<< Slow Search		<<
	Play		Play
	Slow Search >>		>>
	I<< Skip		I<<
	Pause		Pause
	Skip >>I		>>I
	Stop		Stop
	Pop-Up Menu		D. Menu
	Exit		Exit
	Option		Options
	Return		Back
	Top Menu		Menu
	Netflix		Media
	Home		Smart
	Up		Up
	Down		Down
	Right/I>		Right

Original	Replacement
◁ / Left	Left
OK	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Power Tv	SHIFT + Power: Shift + Power
INPUT AV AV Input Tv	TIMER AV: AV
+ VOL Vol + Tv	+ VOL: Vol +
Vol - Tv	VOL −: Vol -

Original	Replacement