Original	Replacement
Power	Power
◴	Sleep
Exit	Exit
I-II	Dual
I.S.	Smart
[i+]	Info
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Smart Audio	Shift + Dual

Original	Replacement
Smart Picture	Format
Menu	Menu
Text / OK	Ok
Text / OK	Text
Up	Up
Left	Left
Right	Right
Down	Down
Vol +	Vol +
Vol -	Vol -
Mute	Mute
P +	Ch +
P -	Ch -
Red / Rec	Red
Red / Rec	Rec
Green / <<	Green
Green / <<	<<

Original	Replacement	Original	Replacement
Yellow / Stop	C Yellow		
Yellow / Stop	Stop		
Blue / Play	D Blue		
Blue / Play	PLAY MODE Play		
[X]	SHIFT + CLEAR EXIT Shift + Exit		
[♦] / ◴	ECO 3D		
[▯] / >>	SHIFT + Stop Shift + Stop		
[▯] / >>	>>		
[/≡]	SHIFT + REPEAT TEXT Shift + Text		
[?]	SEARCH TV/R		
[≡i]	-/-- GUIDE		